

# PRE-TILED SHOWER BASE INSTALLATION GUIDE

---

## INSTALLATION INSTRUCTION FOR SHOWER BASE WITH PRE-INTALLED PVC DRAIN

1. Frame out shower stall area to shower base dimensions.
2. Sweep out any debris from sub floor.
3. Make sure shower base drain fits in subfloor bore hole.
4. Make sure the shower base is aligned properly and fits snugly against the shower frame studs on all sides.
5. This step depends on whether there is access to the drain connection from below the subfloor:
  - a. **If there is access from the subfloor below**, then cut a section of drain pipe (PVC, as applicable to the type of drain) which is long enough to extend below the subfloor and easily make a connection to the waste water pipe.
  - b. **If there is no access from the subfloor below**, then make sure the drain pipe stubbed up from the subfloor is adjusted to a height sufficient to fit properly into the shower base drain connection.
6. There are ribs under the shower base. Calculate the amount of mortar needed by measuring the height from the rib bottoms that rest on the substrate to the underside of the base floor at the deepest point in between the ribs.

**Please note, do not place the mortar directly on a wood or Gyp-crete substrate. First, waterproof the wood substrate with a fluid applied waterproofing membrane or NO. 15 or No. 30 roofing paper so the wood does not absorb the water from the mortar.**

7. **Spread your mortar base (should be a milk shake consistency), EVENLY ACROSS THE SUBFLOOR and offset 1" from each outside edge of the pan with exception of the curb side. Mortar will protrude out from under the curb, run the finished side of trowel along curb face to backfill any excess mortar.**
  - a. **If there is access from the subfloor below** and you followed step 5.a. above, then brush PVC adhesive on the outside of the cut drain pipe and quickly insert into drain connection, and then be sure the drain pipe extends far enough below the subfloor so it can be conveniently connected to the waste water pipe following the installation.
  - b. **If there is no access from the subfloor below** and you followed step 5.b. above then brush PVC adhesive on the drain pipe stubbed up from the subfloor, then quickly insert the stubbed-up drain pipe properly into the shower pan drain.
8. Place the base in the mud base and firmly but gently shimmy the shower base (applying pressure in drain location first) into the mud so that (i) the drain is fully supported by mud at the bore hole in the substrate, and (ii) the ribs are completely filled with the mud alternately applying hand pressure to the right and left sides of the pan floor until the pan ribs come within 1/8" clearance of the subfloor. Level all base sides and the let the mortar dry overnight. **Important: DO NOT STEP INTO THE SHOWER BASE ONCE THE SHOWER BASE HAS BEEN SET AND LEVELED UNTIL THE MORTAR HAS CURED COMPLETELY**
9. Install the shower backer board and water proofing in accordance with the standards established by the Tile Council of North America, Inc.
10. Seal and waterproof joint between backer board and the shower base splash walls using 100% silicone, and then cover the joint with a fluid applied waterproofing membrane on the shower walls over the joint. Allow the mortar bed to dry in accordance with the instructions of the mortar bed manufacturer.