STEP 1: Joint side panel with front face frame STEP 2: Attach top panel with front face frame and side panel STEP 3: Attach top panel with front face frame and side panel STEP 4: Attach back panel on side panel STEP 5: Insert back panel through groove, then screw up STEP 6: Hing door on to front face frame and adjust the cover-space NO. 4 N ω G 0 7 ω DCW2430,DCW2436,DCW2442,DCW****GD DCW2730,DCW2736,DCW2742 9/16"ROUND HEAD SCREW 92 **ASSEMBLY INSTUCTIONS** 3/4" ROUND HEAD SCREW 1"FLAT HEAD SCREW FOR CARCASS 135 DEGREE ANGLE SOFTCLOSE HINGE SHELF CLIP Description BUMPER CLEAT HARDWARE LIST QTY 6 22 5 N N N N 3/4 I " flat head screw 9/16" round head screw "roun" 135° angle PICTURE Bumper ound head screw 0 B STEP:2 STEP:5 Œ **B** (B) \bigcirc \bigcirc T) STEP:3 STEP:6 (C) <u>N</u>O. G Ш O C m ⊳ TOP&BOTTOM PANEL ADJUSTABLE SHELF \bigcirc CABINETS DOOR BACK PANEL BACK PANEL FACE FRAME 0 SIDE PANEL **PARTS LIST** Description (B) STEP:4 STEP:1 QTY N