STEP 5: Fix door onto the frame and adjust the cover-space STEP 4: Attach frame on STEP 3: Joint back panel with side panel and back panel STEP 2: Joint side panel with back panel and attahching top panel for giving support STEP 1: Joint side panel with back panel N0. ω ഗ 6 N 3/4" ROUND HEAD SCREW W3312, W3315, W2418, W3318, W301224, W331224, W301524, W331524, W301824, W331824 W3012,W3612,W3015,W3615,W361524,W3018,W3618,W361824,W361224 1"FLAT HEAD SCREW FOR CARCASS 9/16"ROUND HEAD SCREW ASSEMBLY INSTUCTIONS SOFTCLOSE HINGE Description BUMPER CLEAT HARDWARE LIST QTY 56 4 4 ∞ 4 4 3/4" round head screw 1" flat head screw Cleat 9/16" round head screw **PICTURE** Bumper MILE STEP:1 0 STEP:4 \mathfrak{D} W STEP:2 D STEP:5 N0. (D) Ш U \circ w TOP&BOTTOM PANEL **CABINETS DOOR** FACE FRAME BACK PANEL SIDE PANEL **PARTS LIST** Description STEP:3 QTY