



1. Lower mirror down over frame.
2. Fit side and bottom edges of mirror behind tabs on frame.
3. Determine desired location for mirror on mounting surface.
4. Using supplied nails and wall hangers, hammer 2 nails into each wall hanger and into mounting surface.
5. Make sure both wall hangers are level.
6. Slip hooks on back of mirror over wall hangers.
7. Make sure mirror is hanging level. If mirror is not level slight adjustments can be made by turning hexnut attached to screw on each wall hanger.