





Designed with the plumber in mind.













QUARTER-TURN TEST PLUG





INNOVATIVE FROM TOP TO BOTTOM





TRUE BLUE™ TABLE OF CONTENTS

DESIGNED WITH THE PLUMBER IN MIND	4
TRUE BLUE BATH WASTE KIT	5
TIME-SAVING FEATURES	6
TOOL-FREE INSTALLATION	7
DRAIN GASKET	8
DRAIN TEST PLUG	9
DESIGNER FINISHES	10
ORDERING INFORMATION	12











TRUE BLUE™ BATH WASTE KIT

Introducing True Blue by Dearborn, the next generation of bath waste.

True Blue was thoughtfully designed for pros with a variety of cutting-edge features, like integrated locking components that simplify installation, and quarter-turn test plugs that make testing quick and painless.

True Blue allows you to go from box, to test, to finishing the job in no time.

TRUE BLUE ADVANTAGES

Innovative

- Integrated locking components
- Superior overflow & locking drain gaskets

Plumber-friendly

- Saves time and money
- · Hassle-free, tool-less install

PRODUCTS ARE IN COMPLIANCE WITH THE FOLLOWING CODES:



Uniform Plumbing Code (UPC®)



National Plumbing Code of Canada

IPC

International Plumbing Code (IPC®)

Products are in compliance with the following standards:



ASME A112.18.2-2015/CSA B125.2-15

Flexible





OVERFLOWING WITH TIME-SAVING FEATURES

OVERFLOW TEST PLUG

The quarter-turn test plug comes factory pre-installed, simplifying the job to make testing quick and easy. The True Blue overflow test plug is approved for up to 40 feet of head pressure and doubles as a trim veneer installation tool.

- Overflow cover can be installed with test plug in place and reduces potential for bathroom air locks
- Retestable

A NEXT-GEN GASKET

Because it's made of an innovative foamed rubber material, True Blue's overflow gasket provides better compression and memory than traditional gaskets, creating a more reliable seal that will rebound and prevent leaks.

- Unique foamed rubber material
- Superior compression & memory for a better seal that reduces potential for leak paths

Oatey.com/Dearborn







TOOL-FREE INSTALLATION

The True Blue overflow cover locks with a simple clockwise turn, requiring no additional tools or screws for installation.

And with depth adjustability, it can accommodate various tub styles and thicknesses with an additional clockwise turn.

OVERFLOW COVER FEATURES

- No tools needed
- Depth adjustability to fit many tub styles and thicknesses
- Removable for maintenance
- No set screw required
- High flow rate
- Eliminates need for perfect alignment







TOOLS HIGH Eded Flow Rat





WHILE OTHER OVERFLOW COVERS REQUIRE SCREWS AND PRECISE ALIGNMENT, TRUE BLUE IS A PERFECT INSTALL EVERY TIME





LESS FRUSTRATION EASIER INSTALLATION

Many bath waste installations are performed in tight quarters with limited visibility or little room to maneuver. True Blue improves the process with a set of integrated features to make the job smoother.

DRAIN GASKET FEATURES

- Locking rubber gasket will not move while installing drain spud
- Will not fall off at odd or difficult angles
- Softer durometer for better seal





IT STANDS THE TRUE BLUE™ TEST

DRAIN TEST PLUG

- · Quarter-turn test plug avoids cross-threading and misalignment
- Integrated locking mechanism makes test plug install quick and reliable
- Drain test plug removable with pipe





DESIGNER FINISHES

THREE STYLISH FINISHES

True Blue Bath Waste comes in chrome, brushed nickel and oil-rubbed bronze.

TRIM KITS FOR BRUSHED NICKEL AND OIL-RUBBED BRONZE

- Quickly change trim without removing the spud
- No additional sealants required
- Easily installed with overflow test plug











STOPPER DESIGN OPTIONS













ORDER TRUE BLUE™BATH WASTE

ORDER TRUE BLUE BATH WASTE IN FULL, HALF, ROUGH OR TRIM KITS IN SCHEDULE 40 PVC OR ABS

FULL KIT INCLUDES



HALF KIT INCLUDES



ROUGH KIT INCLUDES



TRIM KIT INCLUDES





FULL KITS ORDERING INFORMATION

PVC



ITEM NO.	DESCRIPTION	CASE QTY	UPC
P9850CP	True Blue PVC Full Kit, Touch Toe Stopper, w/ Test Kit CHR	10	041193104908
P9850BN	True Blue PVC Full Kit, Touch Toe Stopper, w/ Test Kit BN	10	041193104915
P9850RB	True Blue PVC Full Kit, Touch Toe Stopper, w/ Test Kit ORB	10	041193104922
P9860CP	True Blue PVC Full Kit, Uni-Lift Stopper, w/ Test Kit CHR	10	041193104939
P9860BN	True Blue PVC Full Kit, Uni-Lift Stopper, w/ Test Kit BN	10	041193104946
P9860RB	True Blue PVC Full Kit, Uni-Lift Stopper, w/ Test Kit ORB	10	041193104953



FULL KIT P9850CP

ABS



FULL KIT A9850CP (SHOWN ASSEMBLED)

ITEM NO.	DESCRIPTION	CASE QTY	UPC
A9850CP	True Blue ABS Full Kit, Touch Toe Stopper, w/ Test Kit CHR	10	041193104847
A9850BN	True Blue ABS Full Kit, Touch Toe Stopper, w/ Test Kit BN	10	041193104854
A9850RB	True Blue ABS Full Kit, Touch Toe Stopper, w/ Test Kit ORB	10	041193104861
A9860CP	True Blue ABS Full Kit, Uni-Lift Stopper, w/ Test Kit CHR	10	041193104878
A9860BN	True Blue ABS Full Kit, Uni-Lift Stopper, w/ Test Kit BN	10	041193104885
A9860RB	True Blue ABS Full Kit, Uni-Lift Stopper, w/ Test Kit ORB	10	041193104892

TO PLACE AN ORDER

Contact your local Oatey Representative 800-321-9532 | Oatey.com



HALF KITS ORDERING INFORMATION

PVC



PHOTO OF: P9960CP

ITEM NO.	DESCRIPTION	CASE QTY	UPC
P9950	True Blue PVC Half Kit, Touch Toe Stopper, no Test Kit, CHR	10	041193105042
P9950CP	True Blue PVC Half Kit, Touch Toe Stopper, w/ Test Kit, CHR	10	041193105059
P9950BN	True Blue PVC Half Kit, Touch Toe Stopper, w/ Test Kit, BN	10	041193105066
P9950RB	True Blue PVC Half Kit, Touch Toe Stopper, w/ Test Kit, ORB	10	041193105073
P9960	True Blue PVC Half Kit, Uni-Lift Stopper, no Test Kit, CHR	10	041193105080
P9960CP	True Blue PVC Half Kit, Uni-Lift Stopper, w/ Test Kit, CHR	10	041193105097
P9960BN	True Blue PVC Half Kit, Uni-Lift Stopper, w/ Test Kit, BN	10	041193105103
P9960RB	True Blue PVC Half Kit, Uni-Lift Stopper, w/ Test Kit, ORB	10	041193105110
P9960CPZ	True Blue PVC Half Kit, Uni-Lift Stopper, w/ Test Kit, Zinc CHR	10	041193105233

ABS



PHOTO OF: A9950RB

ITEM NO.	DESCRIPTION	CASE QTY	UPC
A9950	True Blue ABS Half Kit, Touch Toe Stopper, no Test Kit, CHR	10	041193104960
A9950CP	True Blue ABS Half Kit, Touch Toe Stopper, w/ Test Kit, CHR	10	041193104977
A9950BN	True Blue ABS Half Kit, Touch Toe Stopper, w/ Test Kit, BN	10	041193104984
A9950RB	True Blue ABS Half Kit, Touch Toe Stopper, w/ Test Kit, ORB	10	041193104991
A9960	True Blue ABS Half Kit, Uni-Lift Stopper, no Test Kit CHR	10	041193105004
A9960CP	True Blue ABS Half Kit, Uni-Lift Stopper, w/ Test Kit CHR	10	041193105011
A9960BN	True Blue ABS Half Kit, Uni-Lift Stopper, w/ Test Kit BN	10	041193105028
A9960RB	True Blue ABS Half Kit, Uni-Lift Stopper, w/ Test Kit ORB	10	041193105035
A9960CPZ	True Blue ABS Half Kit, Uni-Lift Stopper, w/ Test Kit Zinc CHR	10	041193105226

TO PLACE AN ORDER

Contact your local Oatey Representative 800-321-9532 | Oatey.com



ROUGH KITS ORDERING INFORMATION

PVC



ITEM NO.	DESCRIPTION	CASE QTY	UPC
P9970	True Blue PVC Rough Kit, No Test Kit, CHR	10	041193105141
P9975	True Blue PVC Rough Kit, w/ Test Kit, CHR	10	041193105158
P9975Z	True Blue PVC Rough Kit, w/ Test Kit , Zinc CHR	10	041193105257

ABS



ITEM NO.	DESCRIPTION	CASE QTY	UPC
A9970	True Blue ABS Rough Kit, No Test Kit, CHR	10	041193105127
A9975	True Blue ABS Rough Kit, w/ Test Kit, CHR	10	041193105134
A9975Z	True Blue ABS Rough Kit, w/ Test Kit, Zinc CHR	10	041193105240

TRIM KITS ORDERING INFORMATION

TOUCH TOE



PHOTO OF:	K97BN

ITEM NO.	DESCRIPTION	CASE QTY	UPC
K97CP	True Blue Trim Kit, Touch Toe, CHR, No Veneer Included	10	041193105165
K97BN	True Blue Trim Kit, Touch Toe, BN	10	041193105172
K97RB	True Blue Trim Kit, Touch Toe, ORB	10	041193105189

UNI-LIFT



PHOTO OF: K98RB

ITEM NO.	DESCRIPTION	CASE QTY	UPC
K98CP	True Blue Trim Kit, Uni-Lift, CHR, No Veneer Included	10	041193105196
K98BN	True Blue Trim Kit, Uni-Lift, BN	10	041193105202
K98RB	True Blue Trim Kit, Uni-Lift, ORB	10	041193105219















deliver quality. build trust. improve lives.

