

I. General Description

- a. Kits containing items for installing and waterproofing a TriForm shower base

2. Item Codes and Descriptions

- a. ARC571 . . . TriForm Premium Waterproofing Kit
- a. ARC569 . . . TriForm Standard Waterproofing Kit
- a. ARC570 . . . TriForm Pro Waterproofing Kit

3. Physical Characteristics

a. Premium Kit:

- i. 2 gallons of liquid waterproofing compound
- ii. 50 feet of joint reinforcement tape
- iii. 4 internal corner reinforcement pieces
- iv. 1 drain connector
- v. 1 supply gasket
- vi. 3 tubes of adhesive
- vii. 1 tube of acrylic caulk
- viii. 20 — #9 x 2" screws
- ix. 1 Torx bit
- x. 1 paint roller frame
- xi. 2 paint roller covers
- xii. 1 paint brush
- xiii. 2 pair of protective nitrile gloves
- xiv. 1 stir stick

b. Standard Kit:

- i. 2 gallons of liquid waterproofing compound
- ii. 50 feet of joint reinforcement tape
- iii. 4 internal corner reinforcement pieces
- iv. 1 drain connector
- v. 1 supply gasket

c. Pro Kit:

- i. 1 gallon of liquid waterproofing compound
- ii. 25 feet of joint reinforcement tape
- iii. 2 internal corner reinforcement pieces
- iv. 1 drain connector



4. Performance Characteristics

- a. Select the kit that best meets the needs of an installer and/or an installation
- b. Premium kit includes convenience items that an installer may not have on hand
- c. Pro kit is for installation of a TriForm base only (not the shower walls or surrounding floor)
- d. Waterproofing compound, joint reinforcement tape, drain gasket, supply gasket, and drain connector are also available individually if more material is required for a project
- e. Depending on the size and complexity of a project, installers may need more materials to complete walls, a shower bench, niches, surrounding floor, or to make a wet room
- d. Consult Specification and Submittal Forms for information about the following individual items: drain assembly for tile, waterproofing compound, joint reinforcement tape and gaskets, drain connector