



Air Activated Switch Button for Waste Disposal

ROHL Kitchen Accessories

AS425

FEATURES



- Remote on/off air switch button only —Does not include airswitch hardware
- Transmitter button with escutcheon, base and fastening nut included
- 1 1/4" cutout, 1 1/16" to 2" max. depth on deck or wall installation
- Escutcheon and button made of brass

COLORS/FINISHES

- Polished Chrome
- Polished Nickel
- Satin Nickel
- Inca Brass
- Tuscan Brass
- English Bronze

WARRANTY

- Limited Lifetime*
- *No Warranty on Tuscan Brass Finish (TCB)



Consult your local ROHL showroom for additional information and specifications. For complete warranty details and a list of showrooms, go to www.rohlhome.com.