

## **INSTALLATION INSTRUCTIONS** 7074.400

# **COLONY® PRO DUAL CONTROL BAR FAUCET**

Thank you for selecting American Standard... the benchmark of fine quality for over 100 years.

To ensure that your installation proceeds smoothly-please read these instructions carefully before you begin.



Certified to comply with ANSI A112.18.1M

### **RECOMMENDED TOOLS**









Plumbers' Putty or Caulking


Phillips Screwdriver

## **INSTALL FAUCET**

### CAUTION

Turn off hot and cold water supplies before beginning.


• Install FAUCET (1) on lavatory. (No sealant is required unless mounting deck on lavatory is uneven).



### **SECURE FAUCET AND MAKE WATER** SUPPLY CONNECTIONS


- NOTE: Flexible supplies have to be purchased separately.
- Secure FAUCET (1) with ATTACHMENT NUTS (2) supplied. (HAND TIGHTEN).
- Connect water supply to FAUCET (1) with 1/2" IPS FLEXIBLE SUPPLIES (3) or 3/8" O.D. BULL-NOSE RISERS (4). Use adjustable wrench to tighten connections. Do not over tighten. Be careful not to kink copper supply when bending. Use tubing cutter to cut to proper length.

### (HAND TIGHTEN)



## 3 TEST INSTALLED FAUCET

- Remove AERATOR. With handles in OFF position, turn on water supplies and check all connections for leaks.
- Operate both handles to flush water lines thoroughly.
  Replace AERATOR.



SERVICE CAUTION Turn off hot and cold water supplies before beginning.

#### If Faucet Drips, Proceed As Follows:


- Turn HANDLES to OFF position.
- If spout drips, operate HANDLES several times from OFF to ON position. Do not force HANDLES they turn only 90°.
- AERATOR may accumulate dirt causing distorted and reduced water flow. Remove AERATOR and clean before reinstalling.

#### **Change Handle Direction:**

- Remove Plug BUTTON (1), loosen SET SCREW (2) and LIFT UP HANDLE (3).
- Remove Plastic Adapter (4) and cartridge nut (5).
- Lift and turn STOP WASHER 90°.
- Re-install HANDLE components.

#### To Change Cartridge:

- Remove Plug BUTTON (1), loosen SET SCREW (2) and LIFT UP HANDLE (3).
- Remove Plastic Adapter (4) and cartridge nut (5).
- Lift CARTRIDGE (6) off Port (7).
- Clean CARTRIDGE (6) port.
- Place CARTRIDGE (6) onto Port (7) and tighten Cartridge Nut (5) alternately.
- Replace Plastic Adapter (4), HANDLE (3), tighten SET SCREW (2) and install INDEX BUTTON (1).



## 6 CARE INSTRUCTIONS:

DO: SIMPLY RINSE THE PRODUCT CLEAN WITH CLEAR WATER. DRY WITH A SOFT COTTON FLANNEL CLOTH. DO NOT: DO NOT CLEAN THE PRODUCT WITH SOAPS, ACID, POLISH, ABRASIVES, HARSH CLEANERS, OR A CLOTH WITH A COARSE SURFACE.

