









U188424,U189024,U189624
U248424,U249024,U249624
U308424,U309024,U309624

ASSEMBLY INSTRUCTIONS


- STEP 1: Joint side panel with top panel
STEP 2: Joint side panel with middle & bottom panel
STEP 3: Joint side panel with middle & bottom panel
STEP 4: Joint side panel with middle & bottom panel
STEP 5: Attach frame on
STEP 6: Put on the adjustable shelves
STEP 7: Fix door onto the frame and adjust the cover-space

7	SOFTCLOSE HINGE	5	
6	3/4" ROUND HEAD SCREW	5	
5	BUMPER	4	
4	SHELF CLIP	20	
3	9/16"ROUND HEAD SCREW 56		
2	CLEAT	14	
1	1"FLAT HEAD SCREW FOR CARCASS	6	
NO.	Description	QTY	PICTURE


PARTS LIST		
NO.	Description	QTY
A	SIDE PANEL	2
B	TOP&BOTTOM PANEL	3
C	TOE KICK	1
D	FACE FRAME	1
E	BACK PANEL	1
F	CABINETS DOOR	1 OR 2
G	CABINETS DOOR	1 OR 2
H	ADJUSTABLE SHELF	5




STEP:1




STEP:2




STEP:3




STEP:4



STEP:5



STEP:6



STEP:7