



Models/Modelos/Modèles
P6919LF
Series/Series/Seria

RP93988▲
Set Screw & Handle
Tornillo de Presión y Manija
Vis de calage et Manette



RP93990▲-1.5
Wand, Hose Assembly
Cabeza del Rociador y Ensamble de la manguera
Bec-douchette et Tuyau souple




RP93989▲
Bonnet Nut & Cap
Bonete y Casquete
Chapeau et Embase




RP63206
Cartridge Assembly
Ensamble del Cartucho
Cartouche




▲Specify Finish
Especifique el Acabado
Précisez le Fini





RP63207
Weight Assembly
Ensamble de la Pesa
Poids



RP93991▲
(sold separately/Se vende por separado/
Vendu séparément)
Escutcheon, Baseplate & Mounting Nuts
Chapa, Placa y Tuercas
Plaque de finition, Plaque et écrous



RP70251
Gasket (1), Washer (1),
Nut (1) & Screws (2)
Empaque (1), Arandela (1),
Tuerca (1) y Tornillos (2)
Joint (1), Rondelle (1),
Écrou (1) et Vis (2)



RP93100▲
(sold separately/Se vende por separado/
Vendu séparément)
Dispenser Assembly (complete)
Ensamble del Surtidor (completo)
Distributeur (complet)