

This exploded view diagram illustrates the assembly of a shower head. The components are numbered as follows:

- 1**: Main shower head body with a flexible hose.
- 2**: A long, threaded shower head insert.
- 3**: A small O-ring or seal.
- 4**: A small screw or pin.
- 5**: A small O-ring or seal.
- 6**: A small O-ring or seal.
- 7**: A small O-ring or seal.
- 8**: A small O-ring or seal.
- 9**: A small O-ring or seal.
- 10**: A small O-ring or seal.
- 11**: A small O-ring or seal.
- 12**: A small O-ring or seal.
- 13**: A small O-ring or seal.
- 14**: A small O-ring or seal.
- 15**: A small O-ring or seal.
- 16**: A circular shower head faceplate.
- 17**: A small screw or pin.
- 18**: A rectangular shower head base.
- 19**: A small O-ring or seal.
- 20**: A small O-ring or seal.
- 21**: A small O-ring or seal.

Bestelhoeveelheid

Nr.	Artikelnummer	Omschrijving	Installatiehoeveelheid
1	0490031560090	bovendeel	1
2	09184007790	huls	2
3	09160102690	ring	2
4	09121200290	nylon kapje	6
5	0924030811090	verlengstuk	1
6	09230105390	doorstroombegrenzer	1
7	09240318090	nippel	1
8	09141011990	dichting	1
9	09311100490	stift	1
10	091172001ff	uitloop	1
11	09210210890	schijf	2
12	09233002390	moer	2
13	09141502090	ring	2
14	092906020ff	spindel	2
15	09141006090	dichting	2
16	092774001ff	rozet	2
17	09311105590	stift	2
18	092072015ff	greep (hot)	1
19	90230111803ff	perlator	1
20	092072016ff	greep (cold)	1
21	0490031570090	bovendeel	1