












Geberit Montage



D8334-002&BDC © 08-2005







964.152.00.0 (02)

Geberit Montage




■ GEBERIT






Geberit Montage




Geberit Montage








Aufputz Spülkasten
Surface-mounted cistern
Réservoir de chasse apparent
Cassetta di risciacquamento esterna




Geberit Montage









Unterputz Spülkasten
Concealed cistern
Réservoir de chasse encastré
Cassetta di risciacquamento ad incasso




Geberit Montage



Unterputz Spülkasten
Concealed cistern
Réservoir de chasse encastré
Cassetta di risciacquamento ad incasso



Geberit Montage



Wand-WC mit UP-Spülkasten für Betätigung von oben / von vorne
 Wall hung WC with concealed cistern, top / front-operated
 WC suspendu avec chasse d'eau à encastrer pour déclenchement dessus / devant
 Vaso sospeso con cassetta di cacciata incassata da azionare dall'alto / da davanti

