

(\blacksquare): Indicates Steamax nozzle positioning

All dimensions are approximate. Structure measurements must be verified against the unit to ensure proper fit.