

# kitchen sinks

#### **Features**

- $31\frac{1}{2}$ " (800) x  $20\frac{15}{32}$ " (520) / 18" (406) x 9" (229) undermount kitchen sink.
- Double (large/small) compartments.
- 16 gauge 304 stainless steel.
- Smaller sink on right.
- Rear center drain location.
- Brushed finish with highlight rim.
- Superior undercoating for added sound insulation.
- 3mm sound deadening pads on all 4 sink sides and bottom. Up to 3 times heavier than competitive models.
- Fits 36" base cabinet width.

## Components

Product includes: Cutout Template Installation Hardware Installation Instructions

shown with Transolid T3540-PC faucet

# **Options**

TSGM3221D2 Stainless Steel Bottom Sink Grid Set TCBM1117 Bamboo Cutting Board (for small bowl) 2210R Covered Sink Strainer 4010 Covered Disposer Strainer


#### Warranty


Lifetime Limited Warranty



#### **Specified Model**

Model	EPU322-32
Overall Dimensions	L31½" x W20¹5½2" / 1763¼4" x D9" 800 x 520 / 406 x 229
Bowl Dimensions (Left)	L17 <sup>4</sup> / <sub>64</sub> " x W18½" x D9" 448 x 470 x 229
Bowl Dimensions (Right)	L10% x W16" x D7" 270 x 406 x 178
Drain holes:	35%" (92mm)
Shipping Weight	37 lbs.
Material	16 gauge 304 stainless steel
Installation	under counter mounted
Required	template, included





## Codes/Standards


ASME A112.19.3/CSA B45.4

#### **Notes**

Install this product according to the installation instructions.

## **Optional Accessories**

#### TSGM3221D2 Bottom Sink Grid Set




## 2210R Covered Flip Top Sink Strainer.




Water drains easily when cover is in place. Cover flips up with easy touch. Cover makes a flat surface at the sink bottom that prevents food waste from getting into the strainer basket for easy sink clean up. Polypropylene housing. Fits standard 3½" opening.

## 4010 Covered Flip Top Disposer Strainer.



Water drains easily when cover is in place. Cover flips up with easy touch. Polypropylene housing. Top mount installation for 3½" opening.

## 2310 Remote Covered Flip Top Sink Strainer.



Turn the remote knob to open and close drain. Water drains easily when cover is in place. Cover flips up with easy touch.

Cover makes a flat surface at the sink bottom that prevents food waste from getting into the strainer basket for easy sink clean up.

Polypropylene housing. Fits standard 3½" opening. 1¾" hole required in countertop for remote installation. Remote cable 25½" L.