









# 24" Economic Wash Stand User Manual




# Exploded Drawing



| NO. | DESCRIPTION                                                                         | QTY | NO. | DESCRIPTION                                                                          | QTY |
|-----|-------------------------------------------------------------------------------------|-----|-----|--------------------------------------------------------------------------------------|-----|
| 1   |    | 1   | 9   |   | 1   |
| 2   |    | 1   | 10  |   | 1   |
| 3   |    | 1   | 11  |   | 1   |
| 4   |  | 1   | A   |   | 12  |
| 5   |  | 1   | B   |  | 8   |
| 6   |  | 4   |     |                                                                                      |     |
| 7   |  | 4   |     |                                                                                      |     |
| 8   |  | 1   |     |                                                                                      |     |

## STEP 1


Insert the Foot tube(6) into the Left and Right side panels



B  M6x6 8pcs

## STEP 2


Pre-Install the Screw



A  M6x12 8pcs


### STEP 3

Slide the front panel (10) and black panel (11) into the rack



### STEP 4


Installing the Baseboard(9)



A  M6x12 4pcs


## STEP 5

### Installing the Sink(2)




## STEP 6

### Installing the Faucet(1)



## STEP 7

### Installing the Strainer



## STEP 8

### Please remove the protective film before use

