

# Morley™ Technical Specification


## Robe Hook

## DN4003

### Stock Numbers:

- **DN4003BRB – Robe Hook**  
Mediterranean Bronze Finish

### Dimensions:



### Materials:

**Robe Hook** post is die cast from highest quality zinc alloy (Zamac).

### Installation Instructions:

1. Remove mounting posts from the product assemblies by loosening each screw.
2. Position the mounting plate on the wall at desired location with "UP" facing you. Mark hole locations.
3. Drill 2 holes as marked using 5/16" drill bit.
4. Fold ends of the plastic toggle anchor together and insert into each hole in the wall.
5. Lightly tap anchors until flush with the wall.
6. One at a time, insert plastic pin into each anchor and lightly tap to activate anchor. Remove pin and repeat on the other anchor.
7. Place the mounting plate on the wall over the install wall anchors with "UP" facing you.
8. Tighten screws.
9. Place decorative product over the mounting plate with the setscrew facing down. Tighten setscrew.

### Cleaning Instructions:

To preserve the fine finish of this product, clean only with a soft damp cloth. Dry well. Do not use commercial or abrasive cleaners.

**Stock Number:** \_\_\_\_\_ **Robe Hook**  
**By Creative Specialties**