

instruction for installation

Bypass shower door

Preparation

1. After opening all boxes and packages, read this introduction carefully. Check that all of the needed parts are included in the package by marking all the components on the "detailed Diagram of Shower Door Components". Examine boxes and packages for shipping damage. If the unit has been damaged, has a finishing defect, or is missing parts, please contact our customer support department within 3 business days of the delivery date.

2. If this unit is going to be installed in a new construction, install all of the required plumbing and drainage before installing the shower. Use a competent and licensed (if required by local code) plumber for all plumbing installation.

3. Make sure that prior to beginning the installation, the surfaces are leveled and solid and will be able to support the total weight of the unit. Also make sure the walls are at right angles. Irregular installation surface level, radius corners or improper angle of side walls will result in serious problems for your installation. Please note that some adjustments and drilling might be necessary during the installation process.

4. Protect all primary surfaces of the product during installation. Never set your glass down directly onto a tile floor. Leave corner protectors in place until necessary to remove them. Always use a piece of wood or cardboard to protect the bottom edge and corners of the glass prior to and during installation.


5. This unit must be installed upon a finished threshold and against finished walls.

6. This door requires a minimum 3-17/64" of flat threshold space for installation.


7. Note: The installation of this unit requires that you drill down into the threshold.



Attention: This door is extremely heavy and requires professional installation. Two installers recommended.



Tools




Tip: Measure the finished opening before proceeding with the installation to be sure that the correct model size has been ordered.

Be sure to cover the shower drain to prevent losing small parts.

NOTE: Unpack your unit carefully and inspect it. Lay it out and identify all parts using the detailed diagram and packing list in this manual as a reference. Before discarding the carton, check for small hardware bags that may have fallen to the bottom of the box.

NOTE: Retain these installation instructions for future reference.



A




No:	Description	Diagram	QTY
①	Guiderailbracket		2
②	Guiderailconnector		2
③	Top track		1
④	Roller		4
⑤	Antistrippingparts		4
⑥	Door glaas		2
⑦	Wall channel		2
⑧	Bumper block		12

No:	Description	Diagram	QTY
⑨	Handle (option)		2
⑩	Bottom Waterproof profile		1
⑪	Guideblock		1
⑫	Bumper		4
⑬	PMM5x8		4
⑭	Screw St4x30		18
⑮	Wallplugø 6		18



A




①



③





②




④

5


A




⑥




⑧



⑤





⑦




⑨

6


A




①



②





③




④


A




⑤





⑥







⑦





A





A






11




24HRS



To install the sidewall guides, apply silicone on the bottom. Locate side wall guides at base of wall channel. Apply silicone around the wall channels and threshold. Door can be used after 24 hours.

12



B





No:	Description	Diagram	QTY
①	Guiderailbracket		2
②	Guiderailconnector		2
③	Top track		1
④	Roller		4
⑤	Antistrippingparts		4
⑥	Door glas		2
⑦	Bubble strip		4
⑧	Handle (option)		2

No:	Description	Diagram	QTY
⑨	Bottom Waterproof profile		1
⑩	Guideblock		1
⑪	Bumper		4
⑫	PMM5x8		4
⑬	Screw St4x30		18
⑭	Wallplug ø6		18


B




B




①



②





③




④


B




⑤





⑥






⑦







B




B





24HRS



To install the sidewall guides, apply silicone on the bottom. Locate side wall guides at base of wall channel. Apply silicone around the wall channels and threshold. Door can be used after 24 hours.