


Contemporary Round Floor Mounted Tub Filler


Installation Instructions 2064.951

Thank you for selecting American-Standard... the benchmark of fine quality for over 100 years.


To ensure that your installation proceeds smoothly– please read these instructions carefully before you begin.








- Note: Refer to Roughing-in Dimensions on page one for additional information.
- Adequate floor support is required. The WOOD SUPPORT (1) must be a minimum of 2" (51mm) thick by 10" (254mm) wide. **2x6 lumber is NOT adequate for this application.**
- Locate WOOD SUPPORT (1) between floor joists keeping a minimum distance of 2-3/4" (70mm) from the top surface of wood support to the finished floor.
- IMPORTANT: Use a ROUND BUBBLE LEVEL (2) to level the WOOD SUPPORT (1). The WOOD SUPPORT (1) must be perfectly level. Secure WOOD SUPPORT (1) to floor joists. Check for level again.



2 INSTALL HOT AND COLD WATER SUPPLIES

• Sweat together Hot and Cold Supply assemblies. Apply sealing tape to threaded connections. Thread supply assemblies into rough-in valve inlets. The Hot inlet will be on the left when facing the front of the Tub Filler.

Note: The Hot and Cold inlets are marked on the manifold. See View "A".



3 INSTALL ROUGH-IN VALVE

WASHERS (2) supplied.

- Locate the position on the wood support where the ROUGH-IN VALVE (1) will be installed. Use the ROUGH-IN VALVE (1) as a guide to mark the four mounting hole locations. Fig. 1.
- Remove ROUGH-IN VALVE (1) and drill four pilot holes of 3/8" (9mm) in diameter. Fig 2.
- Install ROUGH-IN VALVE (1) onto the 4 MOUNTING SCREWS (2) and tighten NUTS &

*Important: FRONT of ROUGH-IN VALVE (1) must face bath rim. Figure 1.

NOTE: IF INSTALLING ON A CONCRETE SLAB

- Drill four pilot holes of 12.5mm (1/2") in diameter.
- Insert a concrete anchor in each pilot hole.
- Install the 4 MOUNTING SCREWS (2) into the 4 concrete anchors.
 Tighten NUTS & WASHERS (2) supplied.


• Install the 4 MOUNTING SCREWS (2) into wood support.


* Concrete anchor not included. But available commercially.

FRONT

Fig. 1


COLD








- Check that top of the ROUGH-IN VALVE (1) is level in all directions. If the ROUGH-IN VALVE (1) is not level follow the steps below.
- 1. Loosen the four MOUNTING NUTS (2).
- 2. Adjust the LEVELING NUTS (2a) until the TUB FILLER is level in all directions.
- 3. Tighten the four MOUNTING NUTS (2) and check that the TUB FILLER is still level. If adjustment is still required loosen MOUNTING NUTS (2) and adjust LEVELING NUTS (2a).
- Verify that the ROUGH-IN VALVE (1) is level and then fully tighten NUTS & WEASHERS (2).




5 FINISH FLOOR INSTALLATION

- Complete the installation of the Finished Floor. Tile as close to the PLASTER GUARD (3) as you can.
- Caulk between Finished Floor and PLASTER GUARD (3).



6 REMOVE EXPOSED PLASTER GUARD


• Cut the exposed part of the PLASTER GUARD (3) flush with the finished floor. Be careful not not damage the floor.



M965638 REV. 1.3 (10/15)

REMOVE RETAINING PLATE AND SCREWS


• Remove the SIX RETAINING PLATE SCREWS (4) with a (5mm) hex wrench.



8 **REMOVE HOT AND COLD TEST PLUGS**

hex wrench.


Note: Floor is not shown for clarity in this illustration.



HOT

M965638 REV. 1.3 (10/15)





9a INSTALL TUB FILLER

Note: A minimum of four MOUNTING SCREWS (10) are required to secure the tub filler. All six are preferred.

• Install the MOUNTING SCREWS (10) through the MOUNTING PLATE (11) and into the manifold base. Do not fully tighten.

 Rotate the TUB FILLER (12) right or left to align with Tub. Tighten MOUNTING SCREWS (10) with 5mm Hex Wrench to secure TUB FILLER (12).

