TOTO INSTALLATION MANUAL

Clean Dry TM High Speed Concealed Hand Dryer

Warranty Registration and Inquiry

For product warranty registration, TOTO U.S.A. Inc. recommends online Warranty Registration. Please visit our web site http://www.totousa.com. If you have questions regarding warranty policy or coverage, please contact TOTO U.S.A. Inc., Customer Service Department, 1155 Southern Road, Morrow, GA 30260 (888) 295 8134 or (678)466-1300 when calling from outside of U.S.A.



Important Safeguards

(For your safety, please follow the instructions below.)

In this Instruction Manual, the following symbols are shown for safe and proper use of the product and to alert you of the possibility of personal injury and damage to your property.

The symbols and their meanings are as follows:



Ignoring these symbols may cause personal injury and/or property damage.



Ignoring these symbols may cause severe injury and/or property damage.

*Some models may have different components from the ones illustrated below.

<u></u>		
	Do not install the unit in the places where corrosive or combustible gas can be present.	
Do not	This may cause product failure or damage.	
	Never attempt to disassemble for repair or modification.	
Do not disassemble	This may cause electric shock, fire, injury or failure	
	Do not install outdoors or where it is exposed to water.	
Do not use in humid area	This may cause current leakage, electric shock, fire, or failure.	

Marning



It is necessary to install a circuit-breaker in the power supply Failure to do this may cause electric shock during overload or short circuit.

A Caution



The chassis assembly must be installed on a smooth and even wall surface which has enough strength.

Failure to do this may cause damage or personal injury if it falls down.

2

Specification

Product	HDR110#SS
Power Rating	120V AC, 4.25 Amps, 60 Hz, 510 W
Power Connection	Hardwiring
Power Saving Function	Automatically turns OFF after 60 seconds of use
Decibel Rating	58 dB
Air Speed	224 mph (100 meters/second)
Dry Time	12 seconds
Drain Tray Capacity	0.27 gal (950 ml)
Ambient temperature	32° - 104°F (0° - 40°C)
Size	9-5/8" x 18-1/2" x 6-5/16"
Weight	22.2 lbs (10kg)



Before Installing

1. Precautions

- Confirm the rough-in, major dimensions and wiring diagram before installation in order to properly install the hand dryer and electrical wiring.
- All electrical wiring should be installed in accordance with national/local codes and regulations with assistance from a certified electrician.
- Mounting surface should be even and smooth.
- Confirmation must be made that the wall has enough strength for hand dryer installation and be sure to use all the mounting hardware provided to securely install the hand dryer.
- It is necessary to install circuit breaker for the power supply.

2. Others

- Pay special attention so that both the top cover and the sensor surface are not flawed or scratched.
- Do not place other devices using inverter or infrared sensor near the hand dryer, this may cause malfunction.
- * Recommended mounting bracket heights from floor are as follow:
- Male/Female: 29-1/2" (750 mm)
- Children: 23-1/2" (598 mm)
- Handicapped: 21-1/2" (547 mm)





Meets the American Disabilities Act Guidelines, ANSI A117.1 and CSA B651 requirements when mounted in a recessed wall where the front surface is not more than 4" (102mm) from finished wall and max. height of air blower outlet from finished floor is 47-1/4" (1200mm).



Set-up Drawing


Some models may have different components as illustrated below.





Accessories


X Model is subject to change without further notification.





Installation Procedure STEP 1

1 Using template provided, mark the wall for locations and install the mounting bracket.




- 2 Complete the electrical wiring; install the junction box, and connect the power cord using wire nuts.
- 3 Mount the chassis assembly and drain tray assembly
- 4 Install the top cover and drain tray

STEP 1 Mark the wall with template and install the bracket

Caution

Chassis Assy. must be installed on a rigid and even surface Failure to do this may cause damage or personal injury when it falls.

- Attach the bracket firmly on the rigid wall with the three screws (φ4.5×30) provided.
- In the case of a tile or concrete wall, please use plastic plug anchors with screws provided.




- * Recommended mounting bracket heights from floor are as follow:
- Male/Female: 29-1/2" (750 mm)
- Children: 23-1/2" (598 mm)
- Handicapped: 21-1/2" (547 mm)




STEP 2 Complete the electrical wiring

- · Place chassis assembly onto the bottom bracket.
- Using wire nuts, connect power cable from hand dryer to power supply in the junction box (confirm with certified electrician on correct wire nuts to use).
- Place connection point (with wire nuts) into the junction box.
- · Hang chassis assembly onto the top bracket.



STEP 3 Mount the Chassis Assembly and Drain Tray Assembly


- Make sure all electrical wiring is placed away inside the junction box.
- Use 2 screws (M4) that come with the product and tighten unit to the bottom bracket.





1. Checking after installation

- Test the product as follows after the installation is complete.
 - First peel off the seal on the filter. (The seal is used to protect the filter from scratches during shipment; it is no longer needed.)



- 1. Check the circuit breaker
 - Turn the circuit breaker ON.
- 2. Check the functionality
 - Place your hand under the outlet nozzles to see if air blows out.

- After trial run
 - After you check the functionality by trial run, give the user manual (with warranty) to the customer, and explain how to use and maintain the product.

