

### Features

- Modular design allows it to be moved around corners and through doorways with ease.
- Durable high gloss finish.
- Smooth walls with integrated shelves for generous storage space.
- 15" (381 mm) bath depth (floor to top of threshold).
- 60" (1524 mm) x 30" (762 mm) x 72" (1829 mm) complete unit finished dimensions.

### Material

• Compression molded from our exclusive Vikrell® material.

#### Installation

- Four-piece modular design with pivot "snap together" installation.
- Caulk-less seam installation.

### Components

Product includes:

71244100 Smooth Wall Set 71141110 60" x 30" Bath





#### **Codes/Standards**

CSA B45.5/IAPMO Z124 ASTM E162 ASTM E662 Greenguard UL 2818 - Gold HUD, UM Bulletin 73

# STERLING<sup>®</sup> Warranty - Fixtures Made of Solid Vikrell Material

See website for detailed warranty information.

## Available Color/Finishes

Color tiles intended for reference only.

#### Color Code Description

	0	White
-	-	


96 Biscuit

# Accord®

60" x 30" Smooth Bath/Shower



Accord® 60" x 30" Smooth Bath/Shower 71240110



#### **Technical Information**

All product dimensions are nominal.		
Installation:	3-Wall Alcove	
Drain location:	Left	
Basin area, bottom:	46-1/4" x 20-1/2" (1175 mm x 521 mm)	
Basin area, top:	52-1/4" x 22-1/2" (1327 mm x 572 mm)	
Water depth:	11" (279 mm)	
Water capacity:	34 gal (128.7 L)	
Door height required:	56-1/2" (1435 mm)	
Door width required:	56-3/4" (1441 mm)	

#### Notes

Install this product according to the installation guide.

Double studding is recommended for pivot shower door installations.

Studs should be positioned roughly as shown.

Measure your actual product for roughing-in details.

Product is designed to be used with a single-handle mixer valve with an escutcheon cover not to exceed 7-3/4" (197 mm) in width.

Bath cannot be installed without the wall surround.

Width of back wall at top transitions from 60" (1524 mm) at the front to 59-3/8" (1508 mm) in the back corners. Furring strips approximately 1/4" (6 mm) thick should be used at the back corner studs if drywall is to be installed over the nailing flange.