





Olivia/Olenna By-pass Shower Door

INSTALLATION GUIDE



Option 1 - With Wall Profiles




Option 2 - Without Wall Profiles

OR


Each installation shown separately.

TOOLS REQUIRED (Supplied)




2.5mm&4mm&5mm


TOOLS REQUIRED (Not Supplied)



Pencil




Screwdriver



Drill and drill bits
Ø8/25"[8mm]
Ø6/25"[6mm]
Ø1/8"[3mm]




Cutter




Measuring tape



Level



Silicone



Rubber mallet



Safety gloves




Safety glasses




Hacksaw



Masking tape



Wooden Spacer



Professional-grade
Glass suction cup



SAFETY INFORMATION


CAUTION

Please carefully read the following important safety information before handling or installing this shower. There is a risk of serious injury while handling this product. To minimize these risks, please note:

- Always wear safety glasses and gloves while handling.
- Always read and follow all the steps in the installation instructions.
- Inspect all contents and glass for damage before installation.
- Extreme caution should be taken while handling the glass during installation as the tempered glass may shatter if in contact with a hard surface.
- Handle the tempered glass with caution! Improperly handling the glass can cause it to break suddenly in small pieces (never in pointed fragments).
- Always take all precautions not to touch the tempered glass with any tools during the installation, or after installed.
- Do not cut or modify the tempered glass as it will shatter if cut.
- Carefully remove product from packaging and keep packaging until installation is complete.
- Inspect all parts for damage; if there is damage to the unit prior to installation, please contact customer service.
- Install the shower on a floor that is level and able to accommodate the weight of the unit and an occupant.
- Consult local building codes and compliance standards prior to installation and ensure conformity.
- After installation, and from time to time, check the glass for fit and finish to ensure that nothing has come loose since installation.
- Keep this installation manual for future reference.

NOTICE

- Any modification or alteration from what is specified in this instruction manual will void any and all warranty on this product.
- The distributor is not responsible for any damage to the unit or personal property caused by improper installation. If you disregard instructional warnings, you will void your warranty and possibly deal with water damage.
- Consult the distributor's website for any additional information or question on this product's installation.




- You will need at least two people to install this unit properly.
- Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.
- Estimated Assembly Time: 2 hours


















CARE AND MAINTENANCE

- For the daily maintenance, use a wet cloth and a soft liquid cleaner.
- Never use abrasive cleaners containing some acetone, chlorine or strong bleach, scrapers, metallic brushes, nor other objects or the products which can graze or tarnish surfaces.
- Check every 4 months and re-tighten them if necessary.

PACKAGE CONTENT



PACKAGE CONTENT


<p>①</p>  <p>X4</p>	<p>② $\phi 6$</p>  <p>X10</p>	<p>③</p>  <p>X2</p>	<p>④ ST4X35</p>  <p>X8</p>
<p>⑤</p>  <p>X1</p>	<p>⑥</p>  <p>X4</p>	<p>⑦</p>  <p>X2</p>	<p>⑧</p>  <p>X2</p>
<p>⑨</p>  <p>X1</p>	<p>⑩ ST4X25</p>  <p>X2</p>	<p>⑪</p>  <p>X1</p>	<p>⑫</p>  <p>X1</p>
<p>⑬</p>  <p>X1</p>	<p>⑭ M4X5</p>  <p>X4</p>	<p>⑮</p>  <p>X4</p>	<p>⑯</p>  <p>X2</p>
<p>⑰ M5X5</p>  <p>X4</p>			

PART LIST

Part number	Description	Quantity	Code
1	Roller	4	
2	Wall Anchor	10	
3	Wall bracket	2	
4	ST4x35 Countersunk Screw	8	
5	Top Track	1	
6	Bumper Seal	4	
7	Door Panel	2	
8	Handle	2	
9	Left Wall profile	1	
10	St4x25 Countersunk Screw	2	
11	Guide block	1	
12	Water dam	1	
13	Right Wall profile	1	
14	M4x5 Countersunk Screw	4	
15	U Anti-collision block	4	
16	U Wall bracket	2	
17	M5x5 Countersunk Screw	4	

XX indicate hardware finish: PC = Polished Chrome; BS = Brushed Stainless; MB = Matte Black; CB = Champagne Bronze

OPTION 1 - WITH WALL PROFILES



Option 1 - With Wall Profiles




WARNING!

Pages 7-17 as option 1 for installation steps with wall profiles.
If you prefer installation without wall profiles as option 2, please go to pages 18-28.

INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)

1. Measure the finished opening width at the bottom and the model height.
Use these dimensions as **"W1"(TOP)** and **"W2"(bottom)**.
Compare W1 and W2, use the smaller number as finished opening size.
Verify that the model size ordered will fit the finished opening before beginning installation.



WARNING!

This door requires a minimum 3-3/8" flat threshold space for installation







WARNING!

Threshold must be level. The door may not function properly if the threshold is out-of-level.


WARNING!








This door has limited out of plumb adjustment. The door may not function properly if the wall is more than 2" total out of plumb.

◆ INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)

	2 Wall Anchor  X4	3 Wall bracket  X2	4 Countersunk Screw ST4*35  X4	9 Left Wall profile  X1	13 Right Wall profile  X1
---	---	--	--	---	---

Step 1








12 Water dam  X1
--




◆ INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)

	2 Wall Anchor	10 Countersunk Screw ST4*25	11 Guide block
	X2	X2	X1


Step 2



◆ INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)




1 Roller




X4

7 Door Panel




X2

Tear down the diagram




The decorative cover is installed after the commissioning is completed




Step 3

3A





Attaches to the upper part of the door

3B




3C






3D Use caution and safety cover corners when gently placing the shower door down on a dry, flush surface




3E Use caution and safety cover corners when gently placing the shower door down on a dry, flush surface




Easy to hang glass steps


◆ INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)




Step 4



◆ INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)




Step 5





The glass snaps into the guide trough

◆ INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)




Aligning doors to wall via adjusting rollers


Step 6



Loosen main allen screw and turn metal bushing left or right to raise or lower door.
Tighten main allen screw.




Install the interior trim cover




Install the exterior cover



◆ INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)




Step 7



◆ INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)




6 Bumper Seal




X4

8 Handle





X2


Step 8




◆ INSTALLATION STEPS (OPTION 1 - WITH WALL PROFILES)



Step 9



OPTION 2 - WITHOUT WALL PROFILES



Option 2 - Without Wall Profiles




WARNING!

Pages 18-28 as option 2 for installation steps without wall profiles.
If you prefer installation with wall profiles as option 1, please go to pages 7-17.

INSTALLATION STEPS (OPTION 2 - WITHOUT WALL PROFILES)

1. Measure the finished opening width at the bottom and the model height.
Use these dimensions as **"W1"(TOP)** and **"W2"(bottom)**.
Compare W1 and W2, use the smaller number as finished opening size.
Verify that the model size ordered will fit the finished opening before beginning installation.



WARNING!

This door requires a minimum 3-3/8" flat threshold space for installation


WARNING!

Threshold must be level. The door may not function properly if the threshold is out-of-level.

WARNING!

This door has limited out of plumb adjustment. The door may not function properly if the wall is more than 2" total out of plumb.


◆ INSTALLATION STEPS (OPTION 2 - WITHOUT WALL PROFILES)



2

Wall Anchor


X8



3

Wall bracket


X2



4

Countersunk Screw ST4*35


X8



16

U Wall bracket


X2



17

Countersunk Screw M5x5


X4



14

Countersunk Screw M4x5


X4



12

Water dam

X1




15

U Anti-collision block

X4


Step 1

1A




1928mm [75 7/8\"]

1C




φ 6mm


1D




1E




1F



Assemble U Wall bracket





bottom of bracket

1928mm [75 7/8\"]

top of curb or tub

NOTES:

80"overall height=


75 7/8"from top of curb to bottom of bracket

62"overall height=


57 7/8"from top of curb to bottom of bracket

20



◆ INSTALLATION STEPS (OPTION 2 - WITHOUT WALL PROFILES)

	2 Wall Anchor	10 Countersunk Screw ST4*25	11 Guide block
	X2	X2	X1

Step 2




◆ INSTALLATION STEPS (OPTION 2 - WITHOUT WALL PROFILES)



1 Roller


X4




7 Door Panel

X2

Tear down the diagram




The decorative cover is installed after the commissioning is completed




Step 3

3A





Attaches to the upper part of the door

3B



3C






3D Use caution and safety cover corners when gently placing the shower door down on a dry, flush surface




3E Use caution and safety cover corners when gently placing the shower door down on a dry, flush surface

Easy to hang glass steps


◆ INSTALLATION STEPS (OPTION 2 - WITHOUT WALL PROFILES)




Step 4



◆ INSTALLATION STEPS (OPTION 2 - WITHOUT WALL PROFILES)




Step 5





The glass snaps into the guide trough

◆ INSTALLATION STEPS (OPTION 2 - WITHOUT WALL PROFILES)




Aligning doors to wall via adjusting rollers


Step 6



Loosen main allen screw and turn metal bushing left or right to raise or lower door.
Tighten main allen screw.




Install the interior trim cover




Install the exterior cover


◆ INSTALLATION STEPS (OPTION 2 - WITHOUT WALL PROFILES)




Step 7



◆ INSTALLATION STEPS (OPTION 2 - WITHOUT WALL PROFILES)




6 Bumper Seal




X4

8 Handle





X2


Step 8




◆ INSTALLATION STEPS (OPTION 2 - WITH WALL PROFILES)





Step 9






Buffer repair and replacement method



Loosen the fixed block and move it towards the middle

This fixed block doesn't need to be moved



If the buffer is damaged, loosen the briquetting and move it to the middle to take it out and replace it